


Duo Speed
Top part front side

As at: 05/28/08 Time:03:41



Duo Speed

Top part front side

As at: 05/28/08 Time:03:41

Pos.	Description	Reference
01	Top part front side	741.201
02	Top part back side	741.202
03	PT-screw KA 50x25	P...515 L
04	Connection box	741.310
05	Switch compl.	6650454
06	Washer 12x37x3	P...496
07	Hose clamp	P...383 N
08	PT screw KA 40x25	P...516 O
09	Cable clamp	742.321
10	Belt	742.209
11	Security switch	742.208
12	Straight pin 6x50	P...512 M
13	Ball 8 mm	6440641
14	Switch handle	741.204
15	Shaft adjustment lever	741.207
16	Straight pin 8x40	P...512 P
17	Screen red	741.208
18	Antikinksleeve	660011014
19	Cable-tree	742.313
20	Mains cable 12.5 m	656711039
21	Solution tank holder	4711231
22	Cable hook	3711029
23	Hexagon nut M 6	P...490 D
24	Hexagon socket screw M 6x25	P...486 T
25	Millet screw M 6x25	6321596
26	Cover	741.216